

# LUKA












## Assembly Guide

### Attention!







The drawers might need an adjustment if they are not sliding smoothly. Use the Allen key to loosen the runners' screws.








RAGABA




□









7.




8.




9.









10.




11.




**12.****13.****14.****14a.****14b.**


**15.**




**16.**




**16 a.**




**16 b.**




**16 c.**




**19.**




**18.**




**17.**




**20.**




**20 a.**




**20 b.**




**21.**



22.




22.




7


**24a.**




**25a.**




**24b.**




**25b.**




**24c.**




**25c.**




**26a.**




**27.**




28.




29a.



29b.




30.




X2

30.



30a.



30b.

