




01





02



03



04



CASASELECCIÓN®

49918 INSTRUCCIONES DE MONTAJE

1	1PC	2	1PC	3	1PC	4	1PC	5	4PCS	6	2PCS	7	1PC				
A		8PCS		B		2PCS		C		8PCS		D		1PC		Not include	
		D4*25				D6*50				D6*35							